Shallow Flooding Analysis


Sheet Runoff Flooding in Zone A Areas

Sheetflow Flooding Methodology based on

Guidelines and Specifications for
Flood Hazard Mapping Partners

Appendix E: Guidance for Shallow Flooding Analyses and Mapping

http://www.fema.gov/pdf/fhm/frm_gsae.pdf



Guidelines and Specifications for Flood Hazard Mapping Partners


"The general guidelines cited herein are applicable to all areas of shallow flooding. They are indicative of the general approach taken to the study of shallow flooding problems in order to fulfill the requirements of the NFIP."


Appendix E – Section E.5


Shallow Flooding Types


- Sheet Runoff
- Ponding

Sheet runoff is the broad, relatively unconfined down slope movement of water across sloping terrain. Like an AO Zone, these areas have flood depths less than 3 feet.









Guidelines and Specifications for Flood Hazard Mapping Partners


"Two-dimensional models will be used where one-dimensional models, currently accepted techniques, and engineering judgment will not provide satisfactory information for floodplain management and NFIP purposes."


[Appendix C – Section C.3.4.2]


Guidelines and Specifications for Flood Hazard Mapping Partners

"Sheet runoff typically takes place across broad areas of low relief. This makes it likely that sheet runoff depths will be less than 1.0 foot."


Appendix E – Section E.5.3








Shallow Flooding Restrictions Analysis is based on Zone A Boundary Average floodplains less than 3 foot depth Known or easily identified hydrology Shallow areas not extensions of riverine systems








Shallow Flooding Restrictions


- ❖ Analysis is based on Zone A Boundary
- ❖ Average floodplains less than 3 foot depth
- ❖ Known or easily identified hydrology
- Shallow areas not extensions of riverine systems
- Unconfined flooding patterns generally perpendicular to contours


20



Shallow Flooding Restrictions

- ❖ Analysis is based on Zone A Boundary
- ❖ Average floodplains less than 3 foot depth
- Known or easily identified hydrology
- Shallow areas not extensions of riverine systems
- Unconfined flooding patterns generally perpendicular to contours
- $\diamondsuit \ \, \text{Minimal impact from obstructions}$






Guidelines and Specifications for Flood Hazard Mapping Partners

"Shallow flooding is often characterized by highly unpredictable flow direction because of low relief or shifting channels and debris loads. Where such conditions exist, the Mapping Partner shall delineate the entire area susceptible to this unpredictable flow as an area of equal risk."

Appendix E – Section E.5

25



Shallow Flooding Methodology


- ❖ Map and Field Verification
- ❖Cross-section Development
- ❖Normal Depth Analysis

27

Map and Field Verification Verify Zone A Mapping

- ❖Plot Zone A Boundary on Contour Map
- Flood patterns should be downslope and roughly perpendicular to contours







Map and Field Verification Field Check Floodplain Boundary

- Floodplain appears reasonable
- ❖ Raised roads or levees
- Large structures
- Large-scale topographic variations

31









Cross-Section Development


- ❖Topographic Mapping
- ❖3 Cross-sections Preferred
- Cross-Section Location and Spacing


In any shallow flooding analysis, 2-foot contour mapping is the minimum recommended (1 foot is preferred).

If a map cannot be found, then a topographic survey should be performed.









Normal Depth Analysis

Simplified Manning's Equation

$$D = \left[\frac{Q * n}{1.486 * W * S^{1/2}} \right]^{3/5}$$

D = Depth of flow

Q = Quantity of flow

n = Roughness value

W = Width of flow


S = Slope of floodplain topography


	_	_		
Ma	nnin	a's i	n-val	ue*

Type of Channel and Description	Minimum	Normal	Maxim
D. NATURAL STREAMS			
D-1. Minor streams (top width at flood stage < 100 ft			
a. Streams on plain			
1. Clean, straight, full stage, no rifts, or deep pools	0.025	0.030	0.033
2. Same as above, but more stones and weeds	0.030	0.035	0.040
3. Clean, winding, some pools and shoals	0.033	0.040	0.045
D-2. Floodplains c. Brush			
Scatter brush, heavy weeds	0.035	0.050	0.070
Light brush and trees, in winter	0.035	0.050	0.060
Light brush and trees, in summer	0.040	0.060	0.080
Medium to dense brush, in winter	0.045	0.070	0.110
5. Medium to dense brush, in summer	0.070	0.100	0.160




Shallow Flooding Hydraulic Guidelines Limited to average flooding depths







Shallow Flooding Hydraulic Guidelines Limited to average flooding depths Reasonable velocities Ground contour slopes Cross-section spacing


























Avenue Creek Normal Depth
Analysis
$$D_{Structure} = \begin{bmatrix} Q * n \\ \hline 1.486 * W * S^{1/2} \end{bmatrix}^{3/5}$$


$$D_{structure} = \begin{bmatrix} 1,720 * 0.16 \\ \hline 1.486 * 600 * 0.00556^{1/2} \end{bmatrix}^{3/5} = 2.35 \text{ feet}$$

$$Velocity = Q / A = 1,720/(600*2.35) = 1.2 \text{ fps}$$


$$Average Floodplain Depth = 2 \text{ feet}$$


$$(3 \text{ cross-sections})$$































Branch Creek Normal Depth Analysis
$$D_{Structure} = \left[\frac{Q * n}{1.486 * W * S^{1/2}} \right]^{3/5}$$

$$D_{Structure} = \left[\frac{10,000 * 0.05}{1.486 * 7,500 * 0.0014^{1/2}} \right]^{3/5} = 1.05 \text{ feet}$$

$$Velocity = Q / A = 10,000/(7,500*1.05) = 1.27 \text{ fps}$$

$$Average Floodplain Depth = 1 \text{ foot} (3 \text{ cross-sections})$$



